


DIWIWIRE PRO

Table Of Contents

- INTRODUCTION
- HARDWARE SETUP AND SAFETY
- BENDING
- SETTING UP WIREWARE
- PATH MODE
- SCRIPT MODE
- MATERIAL PROFILE
- MAINTAINANCE AND TROUBLESHOOTING

SECTION 1

Introduction



01| INTRODUCTION

Introduction

- THE D.I.WIRE PRO
- D.I.WIRE PRO AND ITS COMPONENTS
- GETTING TO KNOW THE D.I.WIRE PRO

01 | INTRODUCTION

The D.I.Wire Pro

The D.I.Wire Pro is our newest desktop CNC wire bender offering the power, speed, precision and modularity that professionals need. Bend any wire material between 0.027" (0.7mm) and 0.188" (4.8mm), bend strap, and add a straightener and other accessories to optimize production.



The D.I.Wire Pro

Before Use:


- Use the D.I.Wire Pro only as instructed in this manual. Make sure you read all the instructions and safety precautions before using the machine.
- The D.I.Wire PRO is to be used by qualified personnel only.
- This manual contains valuable info about the operation, care and service of your machine. We recommend you keep it handy.

Note: *The instructions in this manual are not meant to cover every possible condition and situation that may occur. Common sense and caution must be practiced when setting-up, operating and maintaining any equipment.*




D.I.Wire Pro and Its Components

THE MACHINE



D.I.WIRE PRO




AC Wall Adaptor
24 Volts 5A



USB allows D.I.Wire to
communicate with the computer

TOOLS AND ACCESSORIES*



BEND HEAD + BEND RING + FEED WHEELS

D.I.Wire comes assembled with your specific Bend Head, Bend Ring and Feed Wheels.

Keep tools and hardware somewhere safe!



CUTTERS



SMALL
TORQUE WRENCH



For the Feed Wheels



SOCKET
WRENCH



LARGE TORQUE WRENCH
For the Bend Head



GUIDES

Guides are custom for
each material diameter.



3/32 HEX KEY



1/8 HEX KEY




5/32 HEX KEY

Used for
all hardware
fasteners


*Your set of tools may differ, depending on what you purchased.

Getting to know the D.I. Wire Pro




Take a few minutes to get oriented to the D.I. Wire Pro.

TOP VIEW




DETAIL



SECTION 02

Hardware Setup And Safety




Hardware Setup And Safety

- GETTING SET UP
- D.I.WIRE ORIENTATION
- SAFETY AND PROTECTION
- DO'S AND DON'TS OF THE MACHINE


Getting Set Up

Start by choosing a work area that is appropriate for your D.I.Wire.


1 CHOOSING A WORK AREA



Place the D.I.Wire away from any surface that could obstruct the air flow and cause overheating. Ideally, you'd place the machine on a sturdy table or work bench by itself.



The D.I.Wire is a heavy machine. Make sure you place it on a hard, flat, and sturdy surface that can support the D.I.Wire's weight and remain flat. Particle boards, thin sheet metal, or wire racks are not strong enough.




Make sure the work area is well illuminated, and kept clean, free of excessive dust, debris and liquids.

D.I. Wire Orientation


The D.I.Wire requires sufficient work space for the following areas:
Back of the system for material loading; front of the system for part bending; and a dedicated area for the computer running WireWare

SPATIAL ARRANGEMENT




Getting Set Up

The D.I.Wire weighs 57 Kg (125 lb). Be safe! Seek assistance to pick it up from its case and to carry it to its assigned work area.




THE D.I.WIRE PRO IS A HEAVY MACHINE AND COULD CAUSE INJURY IF LIFTED INCORRECTLY.

2 UNPACKING THE DIWIRE




To be safe, use assistance while lifting your D.I.Wire PRO.

3 PLUG IN



WHAT'S NEEDED D.I.Wire Pro, USB Cord, Power Cord

ADDITIONAL ELEMENTS Computer




POWER CORD


Only use the only provided power supply. Using other power supplies may damage your machine.

Bend Safety

Your safety and the safety of others is very important to us, so we have provided the following safety section and other safety-related messages along the manual. Always read and follow all safety messages.



NEVER TOUCH MOVING PARTS!



MOVING PARTS NEVER touch the Bend Pins or Feed Wheels during bending. Allow the D.I.Wire to finish bending before reaching into the top plate.

REMOVE JEWELRY Loose jewelry, like necklaces and/or bracelets can get caught in the moving components. Remove all loose jewelry items before operating the D.I.Wire.

AVOID LOOSE CLOTHING Long sleeves, ties, sweaters, hoodies and other loose clothing can get caught in the moving components. Do not wear loose clothing while operating the DIWire

TIE HAIR BACK Long hair can get caught in between the moving components and seriously hurt you. Long hair must always be tied back


TO STOP MACHINE Press STOP or PAUSE in WireWare, or Hit the Power Button
Orient the machine so the switch is easily accessible

POWER OFF Power off your D.I.Wire when not in use

ADULT SUPERVISION REQUIRED Not a toy, the D.I.Wire is intended for use only by or under supervision of adults

AVOID WATER The D.I.Wire and its power supply are not water proof, keep clear of water and other liquids. Refer to the maintenance section for cleaning instructions. Keep the power adaptor away from water
Tip: don't put your coffee cup on top of your D.I.Wire!

Bend Safety



ATTENTION Do not leave the D.I.Wire unattended during operation.



EYE + HAND PROTECTION Always wear protective eyewear when operating the D.I.Wire. Small bits of wire can fly out unexpectedly when bending or cutting the wire. Also, the edge of the wire can be a sharp moving object, eye protection is mandatory.

WORK AREA Always give the D.I.Wire plenty of room to do its work. See the setup section for details.



DO NOT REMOVE PANELS Some hardware components are removable but should not be removed unless instructed by Pensa Labs, or the machine can be rendered unusable. Refer to the service and maintenance section for details.




OVERHEATING The D.I.Wire PRO needs sufficient air flow for proper ventilation. See the Setting Up section for instructions on how to select your work area.



DO NOT TAMPER WITH EXPOSED HARDWARE Removing the covers, modifying the hardware, electronics or switching the power supply can damage the machine and be a potential source for injury. Do not tamper with the machine. It will void your warranty too!

Bending



03 | BENDING


Bending

- LOADING MATERIAL
- CLAMPING AND ALIGNMENT


Loading Material

Loading material into the D.I.Wire is a simple process.

Use the Preset Torque Wrench to loosen the Feed Wheels, then tighten after material is inserted.



1 HOMING SEQUENCE




Before bending, the D.I.Wire needs to go through the homing sequence to ensure the bend pin is in the proper position.

HOME BUTTON Automatically lowers the Bend Ring and causes the machine to locate and rest at Home (machine position zero)

The machine must be homed when turning on the machine, or restarting, or if it has lost position


2 LOAD MATERIAL



Loosen the Feed Wheels with the Preset Torque Wrench.

Load the wire through the Wire Guides (1), into the Feed Wheels (2), and toward the Bend Head (3).

3 START POINT




Load material up until the end is positioned between the Bend Head mandrels.

Tighten the Feed Wheels with the Preset Torque Wrench.

For Path Mode, the path starting position is centered at the Bend Head.


Clamp Adjustment



If the Feed Wheels are slipping, meaning they are not effectively pulling wire through, the Clamp Adjust needs to be modified.

1 PREPARATIONS

WHAT'S NEEDED



TORQUE WRENCH




1/4" HEX BIT

Torque wrench uses a stepped 5/32" to 1/4" hex bit.

You received a pre-set torque wrench that has been selected for your specific application. Do not over-tighten the clamping screw as this may damage your machine or your wire.

2 CLAMP ADJUSTMENT




Turn the Clamp Adjust on the D.I.Wire with the preset torque wrench that came with the machine until it clicks once.

Over time, it is possible to get a feel for variation in how different materials should be clamped. Record clamp force in each Material Profile.

If your application needs higher clamping force, email us at support@pensalabs.com

Setting Up WireWare




Setting Up WireWare

- DOWNLOAD WIREWARE
- PATH MODE
- SCRIPT MODE
- MATERIAL PROFILE MODE

Download WireWare

Download WireWare software to run the D.I.Wire Pro. WireWare prepares your files for bending on the D.I.Wire.



1 INSTALL WIREWARE

After receiving WireWare, download to the computer. Reference the materials that come with the software.

WINDOWS / MAC Choose either Windows or Mac version of WireWare to install on the computer.


2 CONTACT US

We're here to help! For any questions or problems with the download or installation of WireWare, please contact us:

EMAIL support@pensalabs.com

PHONE +1 844-434-9473


Path Mode




Path Mode

Import .SVG files, or create a bend path in Path Mode. It is an interactive workspace to view and edit paths and prepare them for bending. It has been designed to provide basic manipulation and adjustments to bend points and line segments and to manage multiple paths on the work area.

- OVERVIEW
- GETTING STARTED
- PATH & WORKSPACE INFO
- TOOLBAR
- MATERIAL PROFILE SELECTION
- ACTION LIST
- CONTROL & JOG BAR
- ARROW KEY CONTROLS
- OTHER FEATURES




Screen Overview




Getting Started

Import a curve as an .SVG format or create a path.




IMPORT A FILE



Go to File, Open, to open a saved SVG file from your computer.

CTRL + O Quick key to open a file

CREATE A SHAPE




Add Bend (B) and Feed (F) points to the Action List to start creating a new part.

- (+) The Plus icon adds feed and bend points to the list. Clicking the Plus will add a bend and feed after the last segment of a shape.

After adding several Feed/Bend Actions, zoom out to view and manipulate the new set of segments and bend points.

WORKSPACE




The path is a series of bend angles and line segments.

These bend angles and line segments can be manipulated using the tools on the following pages.

Path & Workspace Info

The Path Info section displays properties of the shape and Grid Tools provide Grid Size units and Snap behavior control.



PATH INFO

Overall Width: 101.70 mm	Scale 1
Overall Height: 89.78 mm	Path Length 296.47
Bend Points: 5	Segment Length 10


OVERALL WIDTH Overall width of the path

OVERALL HEIGHT Overall height of the path

BEND POINTS Number of bend points of the active path

SCALE The scale of the part relative to its initial size.

PATH LENGTH The estimated total wire length needed for the part



8.25" (209mm) of extra wire is needed in addition to the path length so that the feed wheels are always engaged.

SEGMENT LENGTH Shows the minimum distance between bend points on a path. Enter a small segment length value to get a smoother curve with many bend points.

GRID TOOLS

Grid Size: 10 mm Snap to Grid Snap to Original Path

GRID SIZE Size of the grid on the workspace and the units in use


Change the units by going to the Edit Tab and selecting Change Units.

SNAP TO GRID Bend points and line segments will snap to the grid as they are moved around on the workspace.

SNAP TO ORIGINAL PATH Bend points and line segments will snap to the ghosted imported path as they are moved around on the workspace.

Toolbar

The Zoom, Select and Undo tools allow for flexible navigation of the workspace and control of the path.



ZOOM



Zoom tools help you to navigate around your workspace.

	FIT TO SCREEN	Resize the view of the workspace to show the entire active part.
	ZOOM IN	Zoom into desired details of the workspace.
	ZOOM OUT	Zoom out to view more of the workspace.
	PAN	Move around the viewable area of the workspace by clicking and dragging.

SELECT



Select Tool allows you to click on line segments and bend points and move them.

	SELECT VERTICES	Click on line segments and bend points to move them around on the workspace.
	ADD A VERTEX	Add new bend points on the active path
	REMOVE A VERTEX	Remove bend points from the active path
	ADD A PAUSE POINT	Select a Bend Point where the machine will pause before the bending at that location
	CHANGE STARTING POINT	Choose which end of the path to start bending

UNDO TOOL




Undo changes made to the Path.

	UNDO TOOL	Click on the Undo Tool to undo changes made on the path
CTRL + U		Undo previous action on the Workspace
CTRL + SHIFT + U		Redo previous action on the Workspace

Material Profile Selection

Selecting the Material Profile that matches the wire in use ensures accurate bending of the Path. A Material Profile is needed to bend from Path Mode or Run WireWare Script commands in Script Mode.



MATERIAL PROFILE



The Material Profile data is used to compensate for the spring back of the wire. Any wire used by the D.I.Wire needs a Material Profile

DROPDOWN MENU Select among saved Material Profiles

In order to modify or create new material profiles go to [Material Profile Mode](#)

SELECTED MATERIAL INFO




Displays the associated Material Alloy, Material Thickness, Feed Wheels and Bend Head


Always make sure to select the proper material profile of the wire you are bending. Using other profiles will make Wireware calculate the wrong compensation angles.

Action List

The Action List shows an editable sequential list of all of the actions that the machine will make while bending the Path.



BENDS (B) & FEEDS (F)




If a file is imported into the Path Mode workspace, WireWare breaks the shape up into Feed and Bend actions.

BEND (B) & FEED (F) FIELDS A sequential list of feed (F) and bend (B) actions and their values.

SELECTION Click on a Bend Point or line segment to see its corresponding Action, or click on the Action to see the corresponding Bend Point/ line in the Path. Change values to adjust Path.

ACTION LIST ADJUSTMENTS




Action List values can be changed on the list and the Path will update on the workspace.

ADJUSTMENT FIELDS Allows for corrections to discrepancies on the bent wire part.

For example, if a 10° Action results in a 9° bend output, simply put a 1° in the adjustment field for a correction.

ADDING TO A SHAPE




Add Bend (B) and Feed (F) points to the Action List to add to the end of a Path.

(+) The Plus icon adds Feed and Bend Points to the list. Clicking the Plus will add a bend and feed after the last segment of a shape.


After adding several Feed/Bend Actions, zoom out to view and manipulate the new set of segments and bend points

Control & Jog Bar

The Control Bar and Jog Bar at the bottom of the workspace can be found in every mode. These controls are **Home** the bend pin, **Bend** the path, and **Stop** the D.I.Wire. The Jog bar shows the location and controls to move the bend pin and feed wheels.



HOME, BEND & STOP



HOME Commands the D.I.Wire to locate and rest at Home (machine position zero)

The machine must be homed when turning on the machine or restarting or if it has lost its location

BEND Starts bending the active path


STOP Immediately stops moving the machine axes

JOG



Jog controls the machine with simple movements set in the numerical fields for each moving part of the machine

This may be helpful for loading wire



SPEED % Shows the speed the machine is running as a percent of the maximum speed determined by machine settings

A Controls position of the bend pin, measured in degrees


X Controls the feed of the wire, measured in the units in use (inches or mm)

Z Controls the up/down position of the pin

ZERO Sets the current position of the specified axis to 0

GO TO Go to the position entered in the jog bar

Arrow Key Controls



Use key commands to manually move the Bend Ring, Bend Pin, or material forward and backward.

1 FEED MATERIAL : X AXIS



CMD / CTRL + UP ARROW
Feeds the material forward

CMD / CTRL + DOWN ARROW
Feeds the material back

2 MOVE BEND PIN : A AXIS



CMD / CTRL + LEFT ARROW
Moves the bend pin counter-clockwise

CMD / CTRL + RIGHT ARROW
Moves the bend pin clockwise


3 RAISE/LOWER BEND RING: Z AXIS



CMD / CTRL + GREATER-THAN
Moves the Bend Ring up (Z0)

CMD / CTRL + LESS-THAN
Moves the Bend Ring down (Z-12 max)

4 INCREMENTAL MOVES




SHIFT + CMD / CTRL + LEFT / RIGHT ARROW
Moves the Bend Pin incrementally (0.5° per move)

SHIFT + CMD / CTRL + UP / DOWN ARROW
Moves the material incrementally (0.20" / 0.5 mm per move)

SHIFT + CMD / CTRL + GREATER-THAN / LESS-THAN
Moves the Bend Ring up and down incrementally (0.047" / 1 mm per move)

Other Path Features

These are other Path Mode tools that are helpful for Path selection, imported file clean up and quick undo/ redo of actions on the Workspace.



PATH SELECTION

SELECT
ESC KEY
Selects the “Select bend points” Tool

NEXT PATH
CTRL+N
Selects the next Path in order of creation, if Workspace has multiple Paths

PREVIOUS PATH
CTRL+P
Selects the Path that was previously selected, if Workspace has multiple Paths

HIDE ORIGINAL FILE
Hides / Shows the ghosted silhouette of the imported SVG

PATH CLEAN UP

Use these tools to modify the imported Path. Paths must be modified to accommodate Bend Head geometry and minimum segment lengths.


SPLIT SELECTED VERTICES
CTRL+J
Divides a selected Bend Point into two equal angle Bend Points.
e.g. a 160 ° bend angle into two 80 ° Bend Points. This allows easier manipulation of larger angles.

DELETE SELECTED VERTICES
BACKSPACE
Deletes selected Bend Point.

PATH CLEAN UP

DELETE SHORT SEGMENTS
Simplifies complex Paths by deleting segments smaller than a threshold relative to the path size.


Script Mode



Script Mode

Create precise shapes using written WireWare script commands or G-Code commands to control the D.I.Wire. These allow for a higher level of control over the output.

- OVERVIEW
- GETTING STARTED
- MATERIAL PROFILE SELECTION
- CONTROL & JOG BAR
- ARROW KEY CONTROLS



Screen Overview

The screenshot displays the DIWire software interface in Script Mode. The window title is "DIWire" and the menu bar includes "File", "Edit", "Mode", "Path", "View", "Machine", and "Help". The interface is divided into several sections:

- FILE INFO**: Located at the top left, it contains a "Material" section with a dropdown menu set to "test_plus". Below this, it lists various material parameters such as "Material Alloy: steel", "Material Diameter: 0.125 in", "Bend Head: 125BendHead_a", "Feed Wheels: 125FeedWheel", "Bend Velocity: 4500", "Feed Velocity: 4500", "Creator Name: steel", "Date: 2017-05-14", "Clamp Torque: test_clamp_t", and "Notes: test_plus_notes". At the bottom of this section, it shows "Maximum Velocity (G0): X: 4500, A: 4500".
- SCRIPT WINDOW**: The central area, titled "Script", shows a list of script lines:


```

1 (Smooth Arc, 125 Galvi)
2
3 REPEAT 30:
4 g90 x2
5 g91 a25
6 g91 a10
7 END
8
9 Feed 10
10
11
            
```
- Script Mode Glossary**: Located on the right side, it contains two tables:
 - WireWare Script**: A table with columns "Script", "Description", and "Example".


Script	Description	Example
FEED	Feeds the wire the specified distance in the units set	FEED 10 - Feeds 10 millimeters or inches depending on the unit set, always in incremental amounts.
BEND	Bends the wire to the specified angle based on the material profile selected	BEND 45 - Puts a clockwise 45 degree bend in the wire
REPEAT n: ... END	Repeats the sequence between REPEAT and END, n times.	REPEAT 3: FEED 10 BEND 90 END Makes a square 10 in/mm
 - G-Code Glossary**: A table with columns "G-Code" and "Description".

G-Code	Description
<i>Parameters</i>	
A	The bend pin's rotational axis which moves in degrees.
X	The feed wheel axis which moves in Inches or millimeters of wire length.
Z	The bend pin's vertical axis which moves in Inches or millimeters depending on units set.
F	Feed rate of the axis in a G1 command.
P	Pause amount in seconds for a G4 command
<i>Commands</i>	
- CONTROL & JOG BAR**: Located at the bottom, it contains four buttons: "HOME", "RUN" (highlighted in blue), "STOP", and "JOG ▲".


CONTROL & JOG BAR

Getting Started

Start a new Script in the Script Window using WireWare Script or G-Code commands.



SCRIPT WINDOW




Click into the Script Window to type in commands or copy and paste text.

WIREWARE SCRIPT + G-CODE Create shapes using the WireWare script commands or G-Code

The Script Window is active when it has a blue outline. Click anywhere outside of the Script Window to be able to use the keys for manually driving the machine. (Page 32)

IMPORT A FILE




Use the file menu to open a saved file from your computer.

CTRL + O Open a file from your keyboard

Paths can be saved as G-Code from Path Mode and opened in Script Mode.

SCRIPT MODE GLOSSARY




This is a glossary of WireWare Script and G-Code commands.


Refer to the Reference section at the end of this manual for a complete glossary of terms and other available commands

Material Profile Selection

When using the WireWare script select a Material Profile to compensate for the wire spring back.



MATERIAL PROFILE



When you select a Material Profile, you will also be able to view its associated information.

Bend Velocity is measured in degrees/minute.
Feed Velocity is measured in mm/minute (in/min).

For more information, see the References section.


DROPDOWN MENU The Drop down menu lets you select among saved Material Profiles in your Library.

Straight G-Code will not use Material Profile information. It's only used for WireWare script commands.


In order to modify or create new material profiles go to [Material Profile Mode](#).

Control & Jog Bar

The Control Bar and Jog Bar at the bottom of the workspace can be found in every mode. These controls are **Home** the bend pin, **Run** the script, and **Stop** the D.I.Wire. The Jog bar shows the current positions and controls to move the bend pin and feed wheels.



1 HOME, BEND & STOP




HOME Commands the D.I.Wire to locate and rest at Home (machine position zero)

The machine must be homed when turning on the machine or restarting or if it has lost its location.

BEND Starts bending the active path


STOP Immediately stops moving the machine axes

2 JOG



Jog controls the machine with simple movements set in the numerical fields for each moving part of the machine.

This may be helpful for loading wire



SPEED % Shows the speed the machine is running as a percent of the maximum speed determined by machine settings

A Controls position of the bend pin, measured in degrees


X Controls the feed of the wire, measured in the units in use (inches or mm)

Z Controls the height of the Bend Pin in relation to the top shape (0 to -12 mm)

ZERO Sets the current position of the specified axis to 0

GO TO Go to the position entered in the jog bar

Arrow Key Controls



Use key commands to manually move the Bend Ring, Bend Pin, or material forward and backward.

1 FEED MATERIAL : X AXIS



CMD / CTRL + UP ARROW Feeds the material forward

CMD / CTRL + DOWN ARROW Feeds the material back

2 MOVE BEND PIN : A AXIS



CMD / CTRL + LEFT ARROW Moves the bend pin counter-clockwise

CMD / CTRL + RIGHT ARROW Moves the bend pin clockwise


3 RAISE/LOWER BEND RING: Z AXIS



CMD / CTRL + GREATER-THAN Moves the Bend Ring up (Z0)

CMD / CTRL + LESS-THAN Moves the Bend Ring down (Z-9 max)

4 INCREMENTAL MOVES




SHIFT + CMD / CTRL + LEFT / RIGHT ARROW Moves the Bend Pin incrementally (0.5° per move)

SHIFT + CMD / CTRL + UP / DOWN ARROW Moves the material incrementally (0.20" / 0.5 mm per move)

SHIFT + CMD / CTRL + GREATER-THAN / LESS-THAN Moves the Bend Ring up and down incrementally (0.047" / 1 mm per move)

Material Profile Mode




Material Profile Mode

A Material Profile can be created for any wire used in the D.I.Wire. Material Profile data is used to compensate for wire spring back during a bend.


A Material Profile is needed to bend from Path Mode or Run WireWare Script commands in Script Mode.

WireWare comes pre-loaded with Material Profiles for wire sold on Pensalabs.com




What is a Material Profile?

When creating a Material Profile the D.I.Wire learns how much to compensate for wire spring back. Material Profiles consist of Hardware Definition information and Dataset measurements.




HARDWARE DEFINITION



The Hardware Definition is information about the Bend Head and Feed Wheels for a specific setup. This information needs to be entered every time a new Material Profile is made.

For more information, see the Reference section.

DATASET MEASUREMENTS




A dataset consists of bending discrete angles, measuring each using a protractor and inputting the results into a table.

It is necessary to complete all three Datasets.

Library Overview

The Material Profile Library is a collection of wire materials that have been calibrated for the D.I.Wire.



MENU BAR

CREATE
NEW PROFILE

EDIT EXISTING
PROFILE

IMPORT & EXPORT
EXISTING PROFILE

DELETE
EXISTING PROFILE

Creating a Material Profile


1 PREPARATION

Prepare the following to create a NEW Material Profile.

MATERIALS NEEDED D.I.Wire, at least ~20 feet (610cm) of wire, cutting tool, preset torque tool and digital protractor.


TIME NEEDED 1-2hrs total

2 CREATE NEW PROFILE



Select the NEW button from the Material Profile Library Screen

3 PROFILE DEFINITION



Fill in the information about the wire and the D.I.Wire hardware setup and click BEGIN when ready to move on.


Red fields are required, others are optional*

To determine the Bend and Feed Velocities for the material being used, see Pensalabs.com for a reference guide.

Clamp Torque affects the Material Profile. Use the preset torque wrench or record torque using a digital torque wrench.

Creating a Material Profile

4 HOME BEND PIN




Before bending, the D.I.Wire needs to go through the homing sequence to ensure the bend pin is in the proper position.

HOME Commands the D.I.Wire to locate and rest at Home (machine position zero)


The machine must be homed when booted or if it has lost its location

5 LOAD WIRE



Load the wire through the Wire Guides, the Feed Wheels and into the Bend Head.

6 BEND




Click BEND to bend your first datapoint. Use the cutting tool to remove the bent wire from the D.I.Wire

The BEND button will bend the angle of the active data field.


Creating a Material Profile

7 MEASURE ANGLE




Measure the angle of the bent wire using a protractor.

8 INPUT



Type measurement into the dataset fields, press the ENTER key to move down to the next datapoint

9 REPEAT & SAVE



Repeat these steps for every datapoint in the Dataset.


SAVE & EXIT Click the Save & Exit button to save a completed or in-progress Material Profile

The file will not show up in the Material Profile drop down lists until all three datasets are complete.

CANCEL Click the Cancel button to exit without saving the file.

Editing a Material Profile


1 EDIT PROFILE



In the Material Profile Library, select the Material Profile to be edited and click the EDIT button.

The blue box will appear around the Material Profile when it is selected


2 EDIT DEFINITION



Make any needed changes to the Material Profile Definition and click BEGIN.

Note that the Bend Head and Feed Wheel types and velocities cannot be changed as the datapoints are linked to this information


3 INITIATE EDITING



Click the EDIT icon next to the datapoint that needs to be edited.

Editing a Material Profile


4 EDIT DATAPOINT



Click BEND to rebend this value and/or input measured angle.

After new numerical value is entered, press the ENTER key to move down.


5 SAVE & EXIT



Save and Exit the Material Profile at anytime if needed. However, this file will not appear in a Material Profile drop down list until all 3 Datasets are complete.

SECTION 07

Maintenance & Troubleshooting




Maintenance and Troubleshooting

- HOW TO CARE FOR YOUR MACHINE
- REPLACING BENDING COMPONENTS
- TROUBLESHOOTING

SECTION 07

How To Care For Your Machine

Cleaning And Lubrication




We recommend applying a way oil lubricant to the following areas:

- Between the top bushing and duck ring
- Between the inner tube and the top bushing


Our team uses PerLube WL-68 for this process. Using a fine tip syringe is helpful when applying lubricant to these tight areas.

Apply once a month, or every 50hr of accumulated use.



Clean any dust or debris from under the feed wheels. The preferred method is by using a vacuum cleaner, but compressed air can also be used. Just make sure to not blow particles into the bearings.

Cleaning And Lubrication



Apply anti-seize grease to the Feed Clamping Screw every 2 months or every 100 to 200 clamping cycles (open-close).

Unscrew the clamping screw completely until fully removed. Inspect the state of the threads and wipe clean with a shop rag or paper towel. Also do a quick inspection of the threads in the nut.

We normally apply a small amount of Moly-Graph #2 grease to the first few threads of the screw and reinsert.

SECTION 07

Replacing Your Bending Components

Replacing Your Bending Components

- REPLACING YOUR BEND RING AND BEND HEAD
- REPLACING YOUR FEED WHEELS
- REPLACING YOUR WIRE GUIDES
- CONFIGURE YOUR D.I.WIRE PRO FOR A DIFFERENT WIRE SIZE

Replacing Your Bending Components


The Bend Head, Bend Ring, Feed Wheels, and Wire Guides are all in constant contact with the wire and they will wear out over time. But don't worry, replacing them is a straight forward process. Follow the steps in this section and you'll be ready to continue bending in no time!

The Bend Head, Bend Ring and Wire Guides also need to be changed if you are reconfiguring your machine for a different wire size. Just follow the same process as for replacing the bending components but use your desired size configuration instead of a replacement kit.

Note:

If your components wore out but you don't have replacement parts, send us an email to support@pensalabs.com to purchase a replacement kit.

Replacing The Bend Head



Replacing The Bend Head

TOOLS REQUIRED



REPLACEMENT
BEND HEAD



TORQUE WRENCH
For the Bend Head



SOCKET
WRENCH



ALIGNMENT
PLATE



MAGNET
(not provided)




5/32 HEX KEY
For Bend Ring



1/8 HEX KEY
For Bend Ramp

Replacing The Bend Head


1



TOOLS 1/8 Hex Key

Remove the ramp / guides by unscrewing all the #10 flathead screws.

2





TOOLS 5/32 Hex Key

Prepare Bend Ring for removal by taking out the 4 #10 bolts that hold it in place.

Replacing The Bend Head

3



TOOLS Magnet (not provided)

Remove the Bend Ring to access the Bend Head.


We did not provide the magnet. It is possible to remove the Bend Ring without a magnet, but the magnet makes the process easier.

Once the Bend Ring is removed, you will have access to the Bend Head.


Different Bend Heads will look different, but all are installed the same way.

Replacing The Bend Head

4



5




TOOLS Bend Head Torque Wrench, 30mm Socket Wrench

The Bend Head is held by an ER20 collet.
Start by loosening the collet nut, but don't remove it completely.


Once the collet nut is loosened, pull the Bend Head out.

Replacing The Bend Head

6



7




TOOLS Replacement Bend Head

Insert the Replacement Bend Head and ensure it is sitting all the way down.

If Bend Head is not able to be all the way down, loosen the collet nut a bit more with your hand.

Replacing The Bend Head


8



While ensuring the Bend Head doesn't lift, hand tighten the collet nut.

Apply downwards pressure to the top of the Bend Head with one hand as you tighten the collet nut with the other

9




TOOLS Alignment Plate

Hold the plate over the Bend Ring area and orient the center with Bend Head.

Most Bend Heads cue the same Alignment Tool, but some may need a different one. If your Bend Head needs a special Alignment Tool, we will send it when we ship the Bend Head

Replacing The Bend Head

10




TOOLS Alignment Plate, WireWare

Using WireWare's manual controls, JOG the Bend Ring until the pins are inline with the alignment plate's holes.

Once the holes for the collet and pins are inline, duck the Bend Ring, and make sure the flats on the tool engage with the flats on the Bend Head.

11



Command your D.I.Wire to go to the 0 position by either:

- Run the Homing cycle by pressing [home]
- Run the following script:
G90 G1 A0
or PINA 0


Type 0 on the jog box for axis A and hit the [go to] button

Verify the Alignment Tool remains fully engaged with the flats on the Bend Head.

The process makes sure the Bend Head is aligned with the 0 position of the machine.

Replacing The Bend Head


12



Insert the Bend Ring back into the system.

Make sure the dowel pins align, and gently press down until the Ring is fully seated.

13




TOOLS 5/32 Hex Key

Fasten the bend ring into place by reinstalling and tightening the 4 #10 screws.

*Do not use excessive force when tightening the screws. 10 lb-in is sufficient.
If you don't have a way to measure the force, go to hand tight plus a quarter turn.*


SECTION 07

Changing The Feed Wheels



Changing The Feed Wheels

TOOLS REQUIRED



**SMALL
TORQUE WRENCH**

For the Feed Wheels



1/8 HEX KEY

For Ramp




3/16 HEX KEY

For Feed Wheel Fasteners

Changing The Feed Wheels


1



TOOLS 1/8 Hex Key

Loosen the fasteners for the ramp.
Remove the ramp from the system.

2




TOOLS Feed Wheel Torque Wrench

Start by clamping the Feed Wheels together by tightening the clamp screw with your Torque Wrench.

Changing The Feed Wheels


3



TOOLS 3/16 Hex Key, Feed Wheel Torque Wrench

With the feed wheels pushed together, loosen and remove the feed wheel fasteners.

4




TOOLS Feed Wheel Torque Wrench

Loosen and fully open the feed wheel carriage to allow the removal of the feed wheels.

Changing The Feed Wheels


5



Remove the Feed Wheels from the D.I.Wire by pulling them out of their shafts.

If the Wheels are too tight, use the help of a strong magnet to pull them out.

6




Insert new Feed Wheels into the D.I.Wire.

Align the keyway on the wheels to the keys on the shafts.
Ensure they are fully seated.

Changing The Feed Wheels


7



TOOLS Feed Wheel Torque Wrench

Tighten the feed carriage.

8




TOOLS 3/16 Hex Key

With the feed wheels pushed together, tighten the feed wheel fasteners.


Changing The Feed Wheels

9



Place the ramp back onto the system.

10




TOOLS 1/8 Hex Key

Tighten the fasteners for the ramp.

SECTION 07

Changing The Guides



Changing The Guides

TOOLS REQUIRED



REPLACEMENT GUIDES


Guides are custom for each material diameter.

1/8 HEX KEY

For Ramp

Changing The Guides


1



TOOLS 1/8 Hex Key

Loosen the fasteners for the ramp.


2



Remove the ramp from the system.


Changing The Guides

3



Flip over the ramp and remove the guides by pulling them out.

4




Insert the new guides into the ramp.
Make sure they are fully seated.

This section describes the process for our most common type of wire guides. If your guides look different and need some help, send us an email to support@pensalabs.com


Changing The Guides

5



Place the ramp back onto the system.

6




TOOLS 1/8 Hex Key

Tighten the fasteners for the ramp.

Troubleshooting

Note:

This section aims to solve the most common issues we have found on the field, but we cannot cover every imaginable scenario. If you can't find your issue in the following tables, or the solution proposed is not solving it for you, feel free to give us a call or shoot us an email at support@pensalabs.com and we will be more than happy to help.



Troubleshooting

Our technical support team at Pensa is here to assist with troubleshooting problems you may experience using the D.I.Wire. You may contact our technical support team via phone, email, or website listed below:

Technical support phone number	+1 844-434-9473
Email	Support@pensalabs.com
Technical support website	https://www.pensalabs.com/support/

What to do before contacting Pensa for technical assistance:

- Have the serial number to your system available
- Be prepared to work with the machine, as many issues will require live troubleshooting
- Check the basic settings of the computer you use to operate the D.I.Wire, such as the operating system and version (e.g. MacOS X / Windows 10)
- A description of the issue, the more detailed, the better

SECTION 08

References

Glossary and Definitions

TERM	DESCRIPTION
HARDWARE	
Bend Head	Static bending mandrels. The center of the bending area that doesn't move.
Bend Ring	Rotating plate that carries the Bend Pin. Rotates around the Bend Head.
Bend Pin	The moving bending mandrel that is mounted on the Bend Ring. This could be a pin pressed on the Bend Ring, or an easy to replace insert
Feed Wheels	The four wheels that drive, or "feed" the wire into the bending area.
WIREWARE SCRIPT	
FEED <i>x</i>	Moves the wire an "x" amount in either inches or mm. The "x" value can be either positive (forward), or negative (backwards) Uses the feed speed defined in the Material Profile
BEND <i>a</i>	Moves the Bend Ring an "a" amount in degrees. The "a" value can be either positive (Clockwise) or negative (counterclockwise). Uses the bend speed defined in the Material Profile
REPEAT <i>n</i> : ... END	A loop that repeats the code between "REPEAT" and "END" an "n" number of times. Very useful when bending many copies of the same part, or bump bending. Currently we do not support nested REPEAT loops (REPEAT within a REPEAT)
PINA <i>a</i>	Moves the Bend Pin an "a" amount in degrees. PINA is a much more convenient way to write the GCode: "G90 G1 A_ F_". The "a" value can be either positive (Clockwise) or negative (Counterclockwise). Uses the bend speed defined in the Material Profile
PINZ <i>z</i>	Moves the Bend Ring a "z" amount in either inches or mm. The "z" value can be either positive (up) or negative (down), but take in account that the maximum travel is from 0 to -10mm, and could vary depending on your bend hardware configuration.
PAUSE	Holds the script until the "Resume" button is pressed. This is equivalent to the "!" in GCode (but we don't support that code). This is different to the G4 GCode command in that PAUSE does not need a time parameter.

Quick Key Commands

MODE	COMMAND	FUNCTION	DESCRIPTION
Global	Command/CTRL + T	Connect	Connect to a plugged in D.I.Wire
	Command/CTRL + O	Open	Open a file in either Path or Script Mode
	Command/CTRL + Q	Exit	Quits WireWare
	Command/CTRL + Shift + C	Material Profile Mode	Switch to Material Profile Mode
	Command/CTRL + Shift + G	Script Mode	Switch to Script Mode
	Command/CTRL + Shift + P	Path mode	Switch to Path Mode
Path	Command/CTRL + S	Save Shape	Saves shape in Path Mode Workspace
	Command/CTRL + Shift + S	Save Shape As	Opens Save As dialog for path in Workspace
	Command/CTRL + U	Undo	Undo last action in Workspace
	Command/CTRL + Shift + U	Redo	Redo last action in Workspace
	Command/CTRL + N	Next Shape	Switch to the next path when there are multiple paths on the Workspace (in order of creation)
	Command/CTRL + P	Previous shape	Switch to the previous path when there are multiple paths on the Workspace
	L	Zoom Extents	Center camera on Path and zoom to fill application window
	Backspace	Delete selected vertices	Delete currently selected Bend Points
	Escape	Select Mode	Switch to select mode
	CTRL + 1	Snap to Grid	Click and drag Path interactions snap to the grid
	CTRL + 2	Snap to Original	Click and drag Path interactions snap to the original shape
	E	Show/Hide Original	Show or hide the original Path outline
	Click and drag + Shift + CTRL	Snap to Horizontal/Vertical	While in the Workspace, snap interactions to horizontal/vertical
Click and drag + Shift + CTRL	Snap to Tangent	While in the Workspace, snap interactions to the tangent line of the next and previous Bend Points	
Click and drag + alt	Pan	While in the Workspace, Pan across the Workspace with mouse	
Script	Command/CTRL + X	Cut	Cut selected text
	Command/CTRL + C	Copy	Copy selected text
	Command/CTRL + V	Paste	Paste text in clipboard
	Command/CTRL + Z	Undo	Undo last changes in Textbox

DIWIWE

BY PENSALABS

<http://www.pensalabs.com>

support@pensalabs.com